


© Product installation and operation guide



TYPE BHP RESIDUAL CURRENT CIRCUIT BREAKER



LIVE ELECTRICAL DISTRIBUTION UK LTD

4 Queensmead Place, Textilose Road, Manchester, M17 1PH
Tel: 0161 8702592 Web: www.liveelectrical.co.uk
E-mail: sales@liveelectrical.co.uk



Ensure that these instructions are made available to the end user for future reference.

TYPE BHP RESIDUAL CURRENT CIRCUIT BREAKER

Description

CEB series is a Type B HP Residual Current Device(RCD) for heat pumps, available in 1P+N and 3P+N up to 100A. It detects AC, pulsating DC, and smooth DC, and is specially optimized for high-frequency leakage from inverter compressors. It operates beyond 20kHz, with a raised 150mA trip threshold above 1kHz, reducing nuisance tripping. Tolerance to DC prevents RCD "blinding" and ensures reliable fault detection.

Compliant with BS7671 for heat pump installs, CEB is a robust, recognized alternative to "B+" RCDs. Its high-frequency and heat pump tuning makes it ideal not only for heat pumps, but also for PV, EV charging, and variable-speed drives.

Technical Data

Time characteristic	Instantaneous
No. of poles	1P+N, 3P+N
Neutral	Switched, N pole on the left
Insulation voltage (Ui)	500V
Rated voltage (Ue)	1P+N: 230/240V~; 3P+N: 400/415V~
Rated currents (I ^Δ n)	16, 25, 40, 63, 80, 100A
Rated sensitivity currents (I ^Δ n)	30, 100, 300mA
Residual current off-time under (I ^Δ n)	≤0.1s
Rated residual making and breaking capacity (I ^Δ n)	500A (In≤50A), 10In (In>50A)
Rated frequency	50/60Hz
Rated conditional short-circuit current (Inc=I ^Δ c)	10kA
Rated impulse withstand voltage (Uimp) (1.2/50μs)	4kV
Dielectric test voltage	2kV (50/60Hz, 1 min.)
Fire resistance (glow-wire test)	960±15°C (Enclosure), 650±10°C (Handle)
Electrical life	2,000 Cycles
Mechanical life	4,000 Cycles
Contact position indicator	green OFF/ red ON
Ground fault indicator	White: Normal; Red: Leakage fault
Protection degree	IP20
Ambient temperature	-25°C ~ +40°C

Storage temperature	-30°C ~ +70°C
Terminal connection type	Cable/ Pin-type/ Fork-type busbar
Max. terminal size for cable	35mm ²
Max. tightening torque	2.5N.m
Installation	Mounting on 35mm DIN rail
Incoming method	Bi-directional
Standard	IEC/EN 62423 (Type B) + IEC/EN 61008-1; Compliant with BS 7671 for heat pump use
Protection	Ground fault (residual current)
Type of trip	Electro-magnetic (RCD)
Residual current type	Type B HP - residual AC, pulsating DC and smooth DC; high-frequency immunity for inverter/heat-pump leakage
HF behavior (Type B HP)	Designed to tolerate switching noise ≥20kHz; for f≥1kHz uses a raised minimum tripping threshold, typically ≥150mA to reduce nuisance tripping


Wiring Capacity

Rated current In (A)	Cross section area s (mm ²)	Tightening torque (N.m)
16	2.5	2.5
25	4	2.5
32	6	2.5
40	10	2.5
63	16	2.5
80	25	2.5
100	35	2.5


Torque settings :

Before powering up the installation check all connections are TORQUED (see table). Loose connections cause fires!

Wiring Diagram




Dimension (mm)




Installation

1. The RCCB is installed in the distribution box, distribution cabinet or box using the TH35-7.5 steel mounting rail.
2. Generally, the RCCB should be installed vertically, with the handle facing upward to power on
3. There should be no significant impact and vibration at the installation place
4. Connection method: Tighten the connection with screws
5. The external magnetic field of the installation site shall not exceed 5 times of the earth magnetic field in any direction
6. Installation and disassembly:



a. Installation: Pull the fixed buckle of the RCCB down in the direction of arrow 1 according to Figure 1, and then put the RCCB in align the rail with the upper end of the installation guide rail (see Figure 1), and ensure that the bottom of the RCCB is fully aligned with the installation guide rail. After that (see Figure 2), push the fixed buckle of the RCCB into the lower end of the installation guide rail according to the arrow direction in Figure 2 to release it.



b. Disassemble: Pull the fixed buckle of the RCCB down in the arrow direction as shown in Figure 3, and then pull the RCCB as shown in Figure 4. The lower end of the RCCB is lifted up and pushed upward, then the RCCB can be removed.

Environment

Waste electrical products should not be disposed of in household waste contact your retailer or local authority for recycling information.