

INSTALLATION & MAINTENANCE MANUAL HBLR









GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.


These instructions should be used to aid installation of the following products: HBLR1 / HBLR2

SAFETY

- Installation of this product should only be carried out by a qualified electrician or competent person to the current Building and IEE Wiring Regulations (BS7671)
- Please isolate mains prior to installation/maintenance

INSTALLATION

• Remove the 4 screws as indicated in Fig 1



- Line up the 4 round screw holes on the reflector with the screw holes on the luminaire
- Using the 12mm screws provided with the reflector, fasten down the 4 screws to secure the reflector to the luminaire
- This will modify the beam angle of HBL high bay units from 120° to 80°





WARNING

Only 4 screws (as indicated) should be removed to install this reflector

GENERAL

The unit should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product.

WARRANTY

This product has a warranty of 1 year from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations, improper use, or removal of the batch codes will invalidate the warranty. If this product should fail within its warranty period it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.









ML Accessories Limited LU5 5TA www.mlaccessories.co.uk

SBNOV17_V1

4