





Instruction Manual

XCE-EOS-SB (WK-EOS)

Backbox Pattress



2025
Version 1.0.0



Contents

1.0 What is the XCE-EOS-SB?.....	3
1.1 Product Image.....	3
1.2 In The Box.....	3
1.3 Product Requirements.....	3
2.0 Installation Instructions.....	4
Appendix 1 - Coverplate Options.....	6

1.0 What is the XCE-EOS-SB?

The XCE-EOS-SB is a pattress designed to house the WK-EOS keypad. The pattress can be mounted in either a UK or EU backbox.

NB

The XCE-EOS-SB is also compatible with the RK-EOS. See the [XCE-EOS-SB \(RK-EOS\) Instruction Manual](#) for more information.

1.1 Product Image



Front (coverplate not included)

Side

NB

The coverplate in the product image above is a separate product; see [Appendix 1 - Coverplate Options](#) for more information.

1.2 In The Box


- Internal pattress (Part B)
- Main pattress body (Part A)
- 4 x M3 x 5mm pan head cross screws

1.3 Product Requirements





- WP-EOS-XX-XX Coverplate (not included) (See [Appendix 1 - Coverplate Options](#))
- WK-EOS Keypad (not included)

2.0 Installation Instructions

The XCE-EOS-SB is in two main parts, labelled below:



1	<p>The XCE-EOS-SB is compatible with UK or EU backboxes.</p> <p>UK BACKBOX</p> <p>EU BACKBOX</p>	<p>Mount Part B to either a UK or EU backbox using the vertical or horizontal fixings.</p>
---	--	--






2		<p>Push the WK-EOS keypad into Part A.</p> <p>Important</p> <ol style="list-style-type: none"> 1. Ensure the WK-EOS is aligned with the pry gap at the bottom of the XCE. 2. Ensure arrows on the pattress plastic are pointing up as shown.
		<p>Push the front section of the WK-EOS keypad into Part A.</p> <p>Once fitted, connect the WK-EOS front section in Part A to the punchdown section inside the backbox via the four-pin connector.</p> <p>For further instructions on setting up the WK-EOS, see the Wired System Setup Guide.</p>
5		<p>Secure Part A to Part B using the four screws.</p>
6		<p>Line up the coverplate clips to the fixing points on Part B and push down firmly to secure the coverplate.</p>

Thank you for choosing Rako Controls; we hope that you are pleased with your system. Should you require further assistance, please contact us via our website, www.rakocontrols.com call our customer support helpline on 01634 226666. The office address is Rako Controls Ltd, Knight Road Rochester, ME2 2AH.



Rako® and the Rako logo are registered trademarks of Rako Controls Ltd. Unauthorised use of these trademarks is prohibited. All other product names, company names, and logos mentioned herein may be trademarks of their respective owners.

Appendix 1 - Coverplate Options

Button Layout	 (01) Polished Brass	 (02) Polished Chrome	 (35) Satin Chrome	 (91) Antique Brass	 (MWH) Matt White	 (YBK) Matt Black	 (09) Matt Bronze
	WP-EOS-60-PB	WP-EOS-60-PC	WP-EOS-60-SC	WP-EOS-60-AB	WP-EOS-60-WH	WP-EOS-60-MB	WP-EOS-60-BM
	WP-EOS-30-PB	WP-EOS-30-PC	WP-EOS-30-SC	WP-EOS-30-AB	WP-EOS-30-WH	WP-EOS-30-MB	WP-EOS-30-BM
	WP-EOS-61-PB	WP-EOS-61-PC	WP-EOS-61-SC	WP-EOS-61-AB	WP-EOS-61-WH	WP-EOS-61-MB	WP-EOS-61-BM
	WP-EOS-31-PB	WP-EOS-31-PC	WP-EOS-31-SC	WP-EOS-31-AB	WP-EOS-31-WH	WP-EOS-31-MB	WP-EOS-31-BM