INSTALLATION GUIDE & USER MANUAL

AST05IP/COB

AST05IP/COB/22
This product contains a light source of energy efficiency class: G. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

AST05IP/COB/27, AST05IP/COB/30, AST05IP/COB/40
This product contains a light source of energy efficiency class: F. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



ENSURE POWER SUPPLY IS OFF WHEN HANDLING ANY ELECTRICAL EQUIPMENT.

Returns & Faulty Items

- If any problem is encountered during or after installation, please call ALL LED technical department to get the problem resolved as soon as possible.
- Please do not just return the item to the outlet you purchased it from, as you are only entitled to a replacement or refund after the unit has undergone testing and the unit has been confirmed as having a manufacturing defect/fault. Your statutory rights are not affected.
- The manufacturer will not be deemed liable or held responsible for any damages caused by faults or manufacturing defects that may be present in any of its products or the misuse or incorrect installation of this device.
- All installations must be carried out in accordance with this installation guide and user manual.
- All goods are supplied under the terms and conditions of ALL LED LTD, a copy of which may be obtained upon written request.



ATTENTION

IF ANY PROBLEMS PERSIST, PLEASE CALL THE ALL LED TECHNICAL DEPARTMENT FOR FURTHER ASSISTANCE.

Environmental Protection Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

The manufacturer will not be deemed liable or held responsible for any damages caused by faults or manufacturing defects that may be present in any of its products or the misuse or incorrect installation of this device. Your statutory rights are not affected.

ALL LED LTD 42 Sedgwick Road, Luton, LU4 9DT
www.allledgroup.com sales@allledgroup.com Tel: +44 (0)208 841 9000

Installation Instructions

1. Ensure surface where LED strip intends to be installed is smooth, adequately cleaned and free of oil and dust.

2. Ensure there are no sharp bends where the strip is being installed. If there are please cut and rejoin the strip either with appropriate cabling or LED strip quick-connectors. Cut the strip at the marked cut-points if necessary.

3. Remove the protective backing from the tape, revealing the adhesive.

4. Firmly press the LED strip onto the cleaned surface ensuring that you have applied even pressure along the length of the strip to ensure adhesion.