

INSTALLATION & MAINTENANCE MANUAL

IP663G / IP665G / OP663GBK / OP665GBK

# **GENERAL INSTRUCTIONS**

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

These instructions should be used to aid installation of the following products: IP663G / IP665G / OP663GBK / OP665GBK

# **SAFETY**

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- Please isolate mains prior to installation or maintenance
- Check the total load on the circuit (including when this product is fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker
- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- · Do not overload this accessory or subject it to conditions outside its rating
- This product is Class I and must be earthed
- This product is IP66 rated (the remote control is IP20 rated)



# **INSTALLATION**

- Provide power to the required point of installation (refer to BS7671 for correct cabling methods). Suitable IP rated junction boxes should be used where required
- Round cable should be used for the mains supply and connected loads. The use of flat cable will cause water ingress
- Remove the fixing screws securing the front cover
- Drill the fixing holes in the rear of the box. Mark the location of the fixing holes and drill
  ensuring not to infringe with any gas/water pipes or electrical cables
- Fix the box to a solid surface using suitable screws and wall plugs (not included). The output compression glands should be facing downwards
- Refit the screw mounting hole caps (failure to fit these caps will compromise the IP rating)
- Unscrew the sealing nut from the compression gland (see Fig. 1) and fit it over the supply cable




Fig. 1




- Remove the protective insert from the compression gland, leaving the rubber gasket and compression gland in place, and pass the supply cable through the compression gland
- Repeat for load cables as required. Each output is individually fused and the rating of the fuse is marked on the PCB. Do not exceed the maximum load shown (see Fig. 2)


	Output 1	Output 2	Output 3	Output 4	Output 5
IP663G / OP663GBK	8A	2.5A	2.5A	-	=
IP665G / OP665GBK	5A	2.5A	2.5A	2A	1A

Fig. 2

• Connect the incoming power ensuring the correct polarity is observed (see Fig. 3): ACL – Live (brown), FGND – Earth (green/yellow), ACN – Neutral (blue)



Connect the various loads ensuring correct polarity is observed (see Fig. 4):
 ACL - Live (brown), FGND -Earth (green/yellow), ACN - Neutral (blue)





- Switch on power to the unit, ensuring it is safe to do so
- See below for matching the remote control to the switch box
- Refasten the cover and secure with the screws provided do not overtighten
- Check for correct operation



# **REMOTE CONTROL SETUP**

- Remove the battery cover from the remote control, insert a 1.5V AAA battery (not included) and replace the cover
- Press and release the "MATCH" switch on the circuit board (see Fig. 1), the green LED indicator will flash
- Press and hold any button on the remote control until the LED indicator on the circuit board is stable and not flashing
- Press the "ON" button on channel 1 of the remote control, the red channel 1 indicator on the box cover will illuminate
- Once channel 1 is programmed the other channels will be set up automatically, the product is now ready for use
- A new remote control can be matched to the switch box by following the procedure above.
   It is not possible to match two remotes to the same switch box, as matching the second remote unmatches the first
- It is possible to match two switch boxes simultaneously onto the same remote, but then the two channel 1s / channel 2s etc can only be switched together







### **WARNING**

This product must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed. The remote control is not weatherproof.

# **GENERAL**

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist

Clean the external surfaces with a damp cloth using a mild solution of detergent and warm water only, do not use aggressive cleaning products or solvents which may damage the product.

Do not use any source of high-pressure washers to maintain or clean this product.

# **WARRANTY**

This product has a warranty of 1 year from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.



### SUPPLIED BY:

### (UK) MANUFACTURER

ML ACCESSORIES LTD, UNIT E CHILTERN PARK, BOSCOMBE ROAD, DUNSTABLE LU5 4LT, WWW.MLACCESSORIES.CO.UK

(EU) AUTHORISED REPRESENTATIVE
SLV LIGHTING GROUP, DAIMLERSTRASSE 21-23,

52531 ÜBACH-PALENBERG, GERMANY

EMAIL: EPREL@GROUP.SLV.COM













DCJUL22\_V3



# **X**nightsbridge

Manufacturers Declaration of Conformity For ML Accessories (Knightsbridge) Electrical products in accordance with CE marking

ML Accessories Ltd. Declare that all products have been designed, manufactured, and tested in accordance with the requirements of the relevant legislation

### CE marking legislation

### In Accordance with the following Directives:

2014/35/EU Low Voltage Directive

2014/30/EU EMC Directive

2014/53/EU Radio Equipment Directive

### Including Legislation

1907/2006 REACH 2015/863 RoHS 2021/341 ERP

#### Safety Standards

Full individual declarations and specific safety standards applicable to relevant product series can be found on our website www.mlaccessories.co.uk

We hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications. The product complies with all essential requirements of the directives.

Scott Brewer Catherine Connolly

Technical Manager CEO

ML Accessories Ltd. Unit E Chiltern Park, Boscombe Road, Dunstable. Bedfordshire, LU5 4LT

This declaration becomes invalid if technical or operational modifications are introduced without ML Accessories Ltd. written consent.

# **X**nightsbridge

Manufacturers Declaration of Conformity For ML Accessories (Knightsbridge) Electrical products in accordance with UKCA marking

ML Accessories Ltd. declare that all products have been designed, manufactured, and tested in accordance with the requirements of the relevant legislation

### UKCA marking legislation

UK SI 2016 No. 1091 Electro Magnetic Compatibility Regulations 2016
UK SI 2016 No. 1101 The Electrical Equipment (Safety) Regulations 2016
UK SI 2012 No. 3032 Restriction of the use of Certain Hazardous Substances in Electrical and

Restriction of the use of Certain Hazardous Substances in Electrical ar

Electronic Equipment Regulations 2012 Radio Equipment regulations 2017

UK SI 2017 No. 1206 Radio Equipment regulations 2017
UK SI 2021 No. 1095 The Ecodesign for Energy-Related Products and Energy Information (Lighting Products) Regulations 2021

### Included Legislation

UK SI 2008 No. 2852 UK REACH UK SI 2013 No. 3113 WEFF

#### Safety Standards

Full individual declarations and specific safety standards applicable to relevant product series can be found on our website **www.mlaccessories.co.uk** 

We hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications. The products comply with all essential requirements of the directives.

Calps...

Scott Brewer
Head of Technical

Catherine Connolly

hnical CEO

ML Accessories Ltd. Unit E Chiltern Park, Boscombe Road, Dunstable. Bedfordshire, LU5 4LT

This declaration becomes invalid if technical or operational modifications are introduced without ML Accessories Ltd. written consent.

