
## SPDPV1000 **INSTALLATION INSTRUCTIONS**












Technical Data	SPDPV1000
Maximum PV DC Voltage - U <sub>CPV</sub>	≤1000V DC
Maximum Continuous Voltage - U₀	1060V DC
Voltage Protection Level - U <sub>P</sub>	≤4kV
Nominal Discharge Current 8/20µs - Iո	20kA
Maximum Discharge Current 8/20µs - I	40kA
Response Time - ta	≤25ns
Tightening Torque	4Nm
Operating Temperature	-40°C to +80°C
Dimensions - W (mm) x H (mm) x D (mm)	54 x 90 x 60
Mounting On	35mm DIN rail
Indication of Status	Flag & Remote
Classification According to BS EN 61643-31	Type 2







Safety Instructions: The device may only be installed by a registered electrician. The device must be checked for external damage or other defects prior to installation, if any damage is found the device must not be installed. It's use is only permitted within the limits stated in these installation instructions. Opening or otherwise tampering with the device invalidates the warranty. This device should be installed in line with the current edition of BS 7671. Each of our devices includes an information sticker which should be attached at or near to the SPD.



